



INSTRUCTION MANUAL

48" CEILING FAN



W-FY4856

220-240V~ 50Hz 27W


HOW TO INSTALL

INSTALLATION INSTRUCTIONS

1. Ceiling fan size more than 600mm, Please hang it 2.3M Height from ground.
2. Screw out first, put blade on, the screw back again.
3. Ceiling fan are hanging on hardcore, make motor vertical, height with no collision advisable
4. DO not hang fans with electric cord directly.




BELOW IS THE INSTALLATION DRAWING:



HOW TO USE

After connecting the plug to the power supply, press the button, the fan can start, and press the button again, the fan will stop.



HOW TO MAINTAIN

This machine can do general performance external cleaning and maintenance, avoid by all means use gasoline or other liquid, the role of plastic have corrosion preventing water seeping into the fan inside the head.