

AKAVEE

ELECTRIC CITRUS JUICER

INSTRUCTION MANUAL



Model: AKV-CJ2119

Read this booklet thoroughly before using and save it for future reference

ADDRESS: L6150, 16TH FLOOR, NO. 117 XING GUANG TING, JINGSHUI YIN ROAD, YUEXIU DISTRICT, 510030 GUANGZHOU


IMPORTANT SAFEGUARDS

Before using the electrical appliance the following basic precautions should always be followed including the following:

1. Read all instructions before using.
2. Before using check that the voltage power corresponds to the one shown on the appliance nameplate.
3. To protect against risk of electrical shock do not put the motor unit in water or other liquid.
4. Unplug from outlet when not use, before putting on or taking off parts, and before cleaning.
5. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
6. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
7. Place the appliance on the flat surface. Do not place on or near a hot gas or electric burner, or in a heated oven.
8. Do not let supply cord hang over the edge of table or counter.
9. Close supervision is necessary when the appliance is used by or near children.
10. Do not use appliance for other than intended use.
11. The appliance can only be used to squeeze the citrus fruit, never use it for juicing other kind fruits.
12. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
13. Children should be supervised to ensure that they do not play with the appliance.
14. Do not use outdoors.
15. Save these instructions.
16. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
17. Warning: Potential injury from misuse.
18. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
19. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.

20. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

HOUSEHOLD USE ONLY



USING YOUR JUICER

Before the first use, Clean top lid, large and small cone, sieve, adjust sieve and cup thoroughly with warm water.

1. Place the cup on the power base, then assemble the sieve onto the rotating shaft.
2. Using the appropriate cone according the fruit size. Small fruit can be squeeze on the smaller cone, while for the large size fruit the two cones have to be used together, that is the large cone put on the small cone.
3. Plug the power cord into the outlet, turning the knob to select desired size of hole, to control the speed of juice flowing.
4. Halve the fruit, put the fruit on the cone and press it lightly and the motor start running. Then the extracted juice will flow into the cup through the sieve, the roughness flesh and pith will be remained on the sieve. The motor may rotate in different direction.

Caution: Never exert excessive force when pressing the fruit to prevent from blocking and damaging motor.

5. Once completing the squeezing, release the hand from the cone and the motor stop running. The appliance is in the idle state. You may restart it again at any time by pressing the cone down

Caution: The appliance shall be on 15s, off 15s, and after 10 consecutive cycles, the appliance must be cooled down for 30 minutes.

Note: the max capacity of the cup is 1000 ml. Make sure do not overfill the cup.

6. When operating is completed or do not use the appliance, unplug the appliance.
7. If depositing the juice in the cup, make sure the top lid is in place. For remaining clean and sanitation.

Caution: when juicer is not use, never hold the two pins of plug while turn the cone by hand as this may result in electric shock.


Cleaning and Maintenance

1. Unplug the appliance and wait it completely cool down before clean.
2. Filter, Reamer, cup. Clean them in hot, sudsy water. Then rinse under running water and wipe dry.

Caution: never use metal polish for cleaning and do not put into dishwasher to clean.

3. Wipe the rotating axis with a soft, damp cloth, never immersed the power base in water or other liquid.
4. Assemble all parts together.

Environment friendly disposal



You can help protect the environment! Please observe local regulations: Dispose of faulty electrical equipment at an official waste collection centre.

