

HAVIT




PJ220 PRO SMART PROJECTOR

PRODUCT MANUAL

PACKING LIST




Projector



HD Cable




AV Cable



Power Adaptor



Remote Control




Warranty Card



User Manual


PRODUCT DESCRIPTION

Projector



IMPORTANT SAFETY CONSIDERATIONS


The following safety instructions ensure the long service life of the projector to avoid fire or electric shock. Make sure to carefully read them and pay attention to all the following warnings.




Do not install the projector in sites with improper ventilation.



Do not install the projector in hot and humid sites.



Do not block the ventilation holes (intake or exhaust)



Do not install the projector in dust and smoke sites.

TROUBLESHOOTING

	Error	Resolution
Does not function when turned on	Power cord loose.	Check both ends of cord and secure firmly.
	Remote battery low.	Replace batteries.
Indistinct text	Projection distance too close or too far.	Adjust distance first, then focus.
	Lens dusty.	Wipe with soft cloth.
Cannot mirroring screen	Phone and projector are not on the same Wi-Fi.	Connect to the same Wi-Fi.
	Software not compatible with phone.	Launch the correct app for Android/iOS.
Sudden power off	Power cord loose.	Check both ends of cord and secure firmly.
	Dust accumulation at intake/exhaust vents, causing poor heat dissipation and overheat protection.	Power off, clean the filter, and restart after cooling.

Scan the QR code to know
more instructions

www.havitsmart.com